



E-scooter



Manufacturer: Shenzhen RND Electronics LTD.
Address: 2F, BlockA, RongXinXing Creative park, Bao'an 71st District, Shenzhen, China
Telephone: +86 755 23593926
Website: www.szrnd.net



E-scooter

(Picture above is for illustration only)

Table of Content

1. Product Description	
1.1 Product Dimensions	2
1.2 Product Structure	3
1.3 Product Specifications	4
1.4 Product Packing List	4
1.5 Assembly Instructions	5
1.6 Folding and Unfolding Instructions	6
1.7 Status Monitor	8
2. Operation Instructions	
2.1 Check List Before Operation	8
2.2 Recommended Instructions for Beginners	9
2.3 Normal Operation for Electric Scooter	9
2.4 Do's and Don'ts for Safe Operation	11
3. Battery and Charger	
3.1 Battery Specifications	12
3.2 Charging Procedure	12
3.3 Charging Tips	13
3.4 Charging Safety Tips	13
3.5 Over Discharge Protection	13
4. Product Maintenance	
Product Maintenance	14


04/ Product Maintenance

- Storage:**
- Avoid placing R1 in long periods of time in direct sunlight, rain, or environments of heavy humidity
 - During long idle periods, perform battery check and battery charge to ensure batteries fully charge and to avoid battery over-discharge.
 - Kick stand is designed for structural support. Avoid standing on R1 while kick stand is down. This action can cause kick stand to crack and break.
- Cleaning:**
- Before washing R1, turn off R1's power switch. Cover DC power receptacle with receptacle cover to prevent water flowing into the power receptacle.
 - Use cloth and clean or soapy water to wipe R1's exterior. Do not immerse R1 in water at anytime.
- Maintenance:**
- If front tire appears crack and leaking, replace front tire immediately.
 - When experience significant reduction in range, replace battery immediately. Please bring used battery to appropriate recycling facility.
 - Replace R1's components via authorized dealers.

01 Product Description

RND Electric Scooter is compact, light weight, and easy to operate. The exterior is sleek and andfashionably chic. The entire body is constructed with high grade metal alloy. It uses lithium battery as energy source and foot accelerator for speed control, giving the rider an comfortable, unique riding experience.

1.1 Product Dimensions



3.3 Charging Tips

During charging, charging indicator light displays current volume of charge with solid light and remaining charging needed with flashing light

3.4 Charging Safety Tips

- First time charging requires 4-6 hours.
- To maximize battery life, please charge battery every other month if idle or two days after the last riding.
- Batteries must be charged in a timely manner. Neglect to do so can cause battery over-discharge which can lead to severe damage to the batteries
- Use charger provided by RND.
- Charging must be conducted in a dry, well ventilated area. Make certain power receptacle is dry. Do not touch power receptacle with wet hands.
- Please use only authorized RND service center for battery, cable, and charger repair.

3.5 Over Discharge Protection

R1 has internal over-discharge protection. When R1 is in shut down state and battery is low, R1 control system will power off to protect the battery bank. In order to bypass over-discharge protection, R1 needs to be charged to wake up. If R1 does not wake up after 30 minutes charging, contact RND authorized dealers or RND post sales service department.

RND E-scooter


03/ Battery and Charger

3.1 Battery Specifications


Specification	Details	备注
1 Battery Type	Lithium Ion	Battery operating temperature cannot exceed temperature specified by this table.
2 Charge Time	4-6 Hours	
3 Battery Model	36V/5.2Ah(187Wh) 36V/6.4Ah(230Wh)	Charge time varies by environment and battery capacity changes.
4 Operating Temperature	Charging: 0-45°C Discharging: -20-60°C	
5 Storage Temperature	-20-45°C	

3.2 Charging Procedure

- Remove power receptacle cover located left side of scooter near the rear wheel. (see below illustration)
- Be sure power receptacle is dry with no moisture.
- Place charger connector into the charging receptacle. Be sure connector is firmly in place.
- When charger indicator light show red, the batter is charging. When charger indicator turns green, the battery is fully charged. Once fully charged, stop charging immediately.



1.2 Product Structure




03/ Battery and Charger

3.1 Battery Specifications

Specification	Details	备注
1 Battery Type	Lithium Ion	Battery operating temperature cannot exceed temperature specified by this table.
2 Charge Time	4-6 Hours	
3 Battery Model	36V/5.2Ah(187Wh) 36V/6.4Ah(230Wh)	Charge time varies by environment and battery capacity changes.
4 Operating Temperature	Charging: 0-45°C Discharging: -20-60°C	
5 Storage Temperature	-20-45°C	

3.2 Charging Procedure

- Remove power receptacle cover located left side of scooter near the rear wheel. (see below illustration)
- Be sure power receptacle is dry with no moisture.
- Place charger connector into the charging receptacle. Be sure connector is firmly in place.
- When charger indicator light show red, the batter is charging. When charger indicator turns green, the battery is fully charged. Once fully charged, stop charging immediately.



1.3 Product Specifications

Specification	Details	
1 Model Name	R1	T1
2 Vehicle Weight	9.9Kg	10.7Kg
3 Max Load	100KG	100KG
4 Top Speed	20KM/h	25KM/h
6 Product size	952x430x1099mm	1050x430x1125mm
7 Battery	Lithium Ion (36V/5.2Ah)	Lithium Ion (36V/5.2Ah) Lithium Ion (36V/6.4Ah)
8 Charge Time (typical)	4-6 Hours	4-6 Hours
9 Tire Type	Front wheel 8 inches inflatable Rear wheel 8 inches solid	Front wheel 10 inches inflatable Rear wheel 10.5 inches vacuum

1.4 Product Packing List

R1 product package includes the following: (please inspect and contact RND authorized dealers or RND post sales support department to replace any missing items.)


Scooter Body	Handle Bar, Handle Bar Cover
Installation tool & Screws	Charger
Owner's Manual, Inspection Certificate	

04/ Do's and Don'ts for Safe Operation

R1 is a motorized scooter. Besides having knowledge on motorized scooter performance, attributes, and driving skills, it is very important to know safety aspects of riding a motorized scooter.

Do's and Don'ts

- Ride with good helmet and protective gears.
- Never traverse water over 30mm deep.
- Be aware of and avoid pedestrians near by.
- Beginners ages less than 18 or over 45 need assistance by his or her side.
- Don't go for speed before having full command of maneuverability. Slow down.
- Never go for incline over 20 degrees. Do not go for sudden acceleration and/or deceleration.
- Scooter wheel diameter is small. Learn to avoid barriers. Never go over barriers above 10mm in height.




Do Not Do

- Avoid riding with one hand.
- Avoid bantering while riding.
- Do not ride up or down stairs.
- Do not immerse scooter in water.
- Do not ride on open road.
- R1 is designed as single person transport. Do not ride more than one person at any time.
- Do not ride on bumpy, slippery roads such as dirt, gravel, snow, or with pot holes


05/ Assembly Instructions

Place handle bar into upper horizontal tube of the steering pole. Aligned mounting holes of two tube together.


01




Step 2: Kick up the kick stand.



Step 3: Grip both hands on handle bar. Use one foot gently press on the accelerator pad. To accelerate, press accelerator pad downwards. To decelerate, lift up from accelerator pad.



Step 4: To brake or stop, place other foot on the mud flap. Press down on mud flap as needed to reduce speed or come to a complete stop.



1.5 Assembly Instructions


Lock M4 screws in place

02



Insert handle bar cover onto handle bar


03



06/ Folding and Unfolding Instructions


Unfolding Scooter

Step 1: unhook the Utility / Locking Hook.




- Notes:
- Press down the mud flap
 - Press Utility / Locking Hook downwards. Open the Utility / Locking Hook

Step 2: Lift handle bar up, turn to a certain angle, avoid hitting splash board. locate folding button.



Folding R1

Step 1: Turn handle a certain degree until folding button is completely away from protective cover. Afterwards, press down folding button.



Step 2: Fold down steering pole, press pole towards mud flap until Utility / Locking Hook until it is lock into place.




07/ Recommended Instructions for Beginners


- Turn on power switch.
- Use foot to kick up the kick stand.
- Place both hands firmly on the handle bar.
- Place one foot on the accelerator pad, use the other foot for a quick kick meanwhile press gently on the accelerator pad. Scooter will accelerate forward.
- Pull in the rear foot, place foot gently on the brake pad. Feet are aligned to front and back configuration. Stand straight, eyes looking forward, control scooter's balance.
- Gently accelerate using accelerating pad. Speed varies by how far the acceleration pad is press downward. Press deeper to increase acceleration. Lift up to slow down.
- When scooter needs to be slowed down or brake, press rear foot down on the mud flap until desire speed or complete stop is reached. Beginners need to learn accelerate, decelerate, and braking techniques.
- When mud flap is press down far enough, acceleration is disabled, and motor is used as brake. Braking recovers force into electricity back into the battery.

08/ Normal Operation for Electric Scooter

Step 1: Press down power switch.



09/ Status Monitor



Battery Indicator: 4 bars, 4 bars meaning full, when battery is low, bars will flash with reminder sound, indicating battery needs charging.

Blue Tooth Indicator: when indicator flashes, it means it is in sync with cell phone app. Setting mode is enabled for changes in setting.

10/ Operation Instructions

2.1 Check List Before Operation

R1 in normal operation involves a few mechanical and electronic settings. Before riding, inspect each component of the vehicle to ensure normal operation. Below are points to pay attention to:

- Be sure that Utility / Locking Hook locked in place.
- Check to make sure handle bar screws are not loose
- Check tires for damage, ensure front tire is properly inflated.
- Check to make sure battery is fully charged.
- Be sure to read operation manual before riding for the first time and fully understand scooter operation.
- Be sure brake is operating normally.